Simplicity®

36" SNOW PLOW & GRADER BLADE Mfr's. No. 335



FOR USE WITH WONDER BOY RIDERS Mfr's. No. 329 & 332

ASSEMBLY

1. Position the Blade Hitch assembly (A) under the front of the tractor as shown, and fasten securely in place with 2 capscrews, lockwashers, and hex nuts (B), noting that the transport chain is attached to the screw on the right (Q).

2. Attach the Push Bar assembly (E) to the Blade Hitch assembly by aligning the mounting holes in the arms of Push Bar and in ends of Blade Hitch assembly arems, and inserting Pivot Pin (F). Hold Pivot Pin in place with a Spring Clip and Cotter Pin (G).

3. Fasten the Foot Lever assembly (H) to the left side of the Push Bar with a 3/8-16 x 1-1/4 hex head Capscrew and lockwasher and hex nut at point (J).

4. Mount the Blade assembly (K) to the Push Bar (E), using the Vortical Pivot Pin (L) and cotter pin as shown. The Blade may be set in any of three positions - to angle to the right, to the left, or straight ahead - depending on which hole the Pin (M) is placed into.

5. The Shoes (N) on the Blade permit the Blade to be raised when plowing snow on gravel or uneven concrete. To raise or lower the Shoes, remove the bolts in the Shoe posts and relocate the posts to the desired position. Replace the bolts and tighten securely. Be sure the post setting is the same on both sides.

6. To transport the Blade, depress the Foot Lever and faston the end of the Transport Chain to the hole (P) in the Push Bar assembly using a Pin and Spring Clip as shown.

1266

36" SNOW PLOW & GRADER BLADE



PARTS LIST

Ref. No.	Part No.	Description
A	107033	Blade Assembly, 36''
B	107024	Shoe Assembly
C	703003	Carriage Bolt, 3/8-16 x 1
D	720002	Lock Washer, 3/8
E	717003	Hex Nut, Full, 3/8-16
F	107063	Pivot Pin (Vertical)
G	722014	Cotter Pin, 5/32 x 1
H	8181003	Pivot Pin
J	107020	Pivot Pin, (Horizontal)
K	8161045	Spring Clip
L	722015	Cotter Pin, 5/32 x 1
M	107012	Push Bar Assembly

Ref. No.	Part No.	Description
N	107090	Blade Hitch Assembly
P	107068	Foot Lever Assembly
Q	705016	Hex Capscrew, 3/8-16 x 1-1/4
R	720002	Lock Washer, 3/8
S	717003	Hex Nut, Full, 3/8-16
T	107031	Foot Lever Chain
U	153058	Lock Pin
V	8161045	Spring Clip
W	705010	Hex Capscrew, 3/8-16 x 1-3/4
X	720002	Lock Washer, 3/8
Y	717003	Hex Nut, Full, 3/8-16
Z	705009	Hex Capscrew, 3/8-16 x 1-1/2
AA	719001	Plain Washer, 3/8

LITHO IN U.S.A